

FENDER CHAMP-AMP LAYOUT NOTICE

MODEL 5C1

F-DH

VOLTAGES READ TO GROUND
WITH ELECTRONIC VOLT METER
VALUES SHOWN + OR - 20%

